


/ & 6HUV\$ & 6HYR' UYH

8 VUV0 DQDO


Chapter I Safety Precautions	1
Chapter II Electrical Specifications	1
2.1 Specifications	1
2.2 Drive model	2
Chapter III Installation	3
3.1 Installation of servo drive unit	3
3.1.1 Installation environment	3
3.1.2 Installation method	3
3.1.3 Installation dimensions	4
3.2 Servo motor installation	4
3.2.1 Installation environment	4
3.2.2 Installation method	4
Chapter IV Wiring	5
4.1 Terminal description	5
4.2 Main circuit wiring	6
4.2.1 Definition of main circuit terminals	6
4.2.2 How to use the main circuit power terminal (spring type)	6
4.2.3 Drive wiring diagram	7
4.3 Definition of wiring terminal	8
4.3.1 Definition of communication terminals (CN1/CN2)	8
4.3.2 Definition of control terminals (CN1)	8
4.3.3 Encoder terminal definition (CN2)	9
4.4 Control signal terminal wiring	11
4.4.1 DI input circuit	11
4.4.2 High-speed pulse input circuit	11
4.4.3 DO output circuit	13
4.4.4 Analog input circuit	13
4.4.5 Pulse feedback output circuit	13
Chapter V Panel Display and Operation	14
5.1 Panel introduction and description	14
5.1.1 Description of panel keys	14
5.1.2 How to operate keys on the panel	14
5.1.3 Status display	14
5.1.4 Display of parameter number	15
5.1.5 Parameter value display	15
5.1.6 Monitor parameter display (POB set parameters)	15
5.2 Common operations	17
5.2.1 O mode operation	17
5.2.2 Internal power-up enable	17
5.2.3 Initialization parameters	17
5.2.4 Manual reset alarm	17
Chapter VI Control Mode Description	18
6.1 Location mode description	18
6.1.1 Position mode wiring diagram	18

6.2	Speed mode description	21
6.2.1	Speed mode wiring diagram	21
6.2.2	Functions related to external speed mode	22
6.2.3	Internal multi-speed related functions	23
6.3	Torque mode description	24
6.3.1	Torque mode wiring diagram	24
6.3.2	Functions related to external torque mode	25
6.4	Detailed description of DI/DO port function configuration	27
6.4.1	DI function description	27
6.4.2	DO function description	30
Chapter VII Parameter Description		32
7.1	P01 set drive parameters	32
7.2	P02 set basic control parameters	32
7.3	P03 set terminal input parameters	33
7.4	P04 set terminal output parameters	34
7.5	P05 set position control parameters	34
7.6	P06 set speed control parameters	37
7.7	P07 set torque control parameters	38
7.8	P08 set gain parameters	39
7.9	P09 set self-tuning parameters	40
7.10	P0A set fault and protection parameters	40
7.11	P0B set monitoring parameters	41
7.12	P0C set communication parameters	42
7.13	P0D set auxiliary function parameters	43
7.14	P11 set multi-segment position function parameters	44
7.15	P12 set multi-segment speed parameters	46
7.16	P17 set virtual DIDO parameters	48
7.17	P30 set communication reading servo related variables	50
7.18	P31 set communication given servo related variables	51
Chapter VIII Troubleshooting		51
8.1	Fault and Warning Code List	51
8.1.1	Fault code table (to reset the fault, you need to cancel the enable first)	51
8.1.2	Warning code table (warnings can be reset directly, no need to disable)	54
Chapter IX MODBUS Communication		55
9.1	Wiring and Setup	55
9.1.1	Topology structure	55
9.1.2	Related parameters	55
9.1.3	Communication address description	56
9.2	MODBUS communication protocol	56
9.2.1	Read register command (0x06)	56
9.2.2	Write single-register command (0x06)	57
9.2.3	Write multi-register command (0x10)	58
9.2.4	Response exception and error codes	59
9.2.5	CRC check	59

2.2 Drive model



2.3 Motor model





Chapter III Installation



3.1 Installation of servo drive unit




℃
℃



Chapter IV Wiring



4.1 Terminal description



4.2 Main circuit wiring

4.2.1 Definition of main circuit terminals

◆ Input power terminal



No.	Signal definition	Functions

◆ Braking resistor terminal


Pin	Signal definition	Functions	Description





◆ Motor terminal

Socket No.	Signal definition	Functions



4.2.3 Drive wiring diagram









Motor side	Name	Wire color





Motor side (Amp plug)	Name	Wire color

Motor side (aviation plug)	Name	Wire color

4.4 Control signal terminal wiring





4.4.1 DI input circuit





Note: With external resistor wiring, when signal voltage $VCC=24V$, $R=1.5K\Omega$; when signal voltage $VCC=12V$, $R=1K\Omega$;
 When signal voltage $VCC=5V$, $R=0\Omega$.


4.4.3 DO output circuit




Chapter V Panel Display and Operation

5.1 Panel introduction and description

5.1.1 Description of panel keys



M	
▲	
▼	
◀	
SET	



RESET			
nrd			

rdy			
run			
dog			

PO 1.00


- Signed number with no more than 4 digits or unsigned numbers with no more than 5 digits
Displayed on a single page (5-digit nixie tube); for signed numbers, the highest digit of the data - represents a negative sign.

Example: -9999 is displayed as follows:

-9999



65536

- Signed numbers with more than 4 digits or unsigned numbers with more than 5 digits
Displayed in pages from low to high digits, and every 5 digits is a page. Display method: current page current page value, as shown in the figure below, press and hold the ◀



--	--	--	--


5.2 Common operations



Chapter VI Control Mode Description

6.1 Location mode description

6.1.1 Position mode wiring diagram



1. Related DI functions can be controlled by external DI, or through virtual VDI for communication control

DI function code	Symbol	Function name	Function description

2. Related parameters


No.	Parameter name	Setting range	Functions
			: 1

3. Combination method when using DI port to switch internal multi-speed

Segment No.	DI port combination mode				Internal speed	Running Time	Acceleration and deceleration Time

6.3 Torque mode description

6.3.1 Torque mode wiring diagram



6.4 Detailed description of DI/DO port function configuration

6.4.1 DI function description

1. DI port configuration parameters:

DI port	Function selection			Logic level	

2. DI port function command table

DI port	Function selection			Logic level	

		0-					
		1-					
		2-					
		3-					
		4-					
		5-					
		6-					
		7-					
		8-					
		9-					
		10-					
		11-					
		12-					
		13-					
		0-					
		1-					
		2-					
			0	25			
		1-	-				
		0-	05-36	-			
		1-	05-36	-			
		2-	05-36				
		3-	05-36				
		0-					
		1-					

--	--	--	--	--	--	--	--

7.7 P07 set torque control parameters

		0- 1- 2- 3- 4-					
		0- 1- 2- - 3- 4- - -					
		0- 1- - 2- 07-19 36 - 07-20					

		0- 1-					
		0- 1-					
		0- 1-					
		0- 1-					
		0- 1-					
		0- 1- 2-					
		0- 1-					

7.11 POB set monitoring parameters

		0- 1- 2- 3-	2 1 1 1				
		0- 1-					
		0- 1-					
		0- 1-		0	0		
		0- 1- 0- 1-	16 16	16 16			

7.13 P0D set auxiliary function parameters

		0- 1-					
		0- 1-					
		0- 1- 0-					
		0- 1- 2- 3-					
		0- 1- 2- 0- 1-		- -			

		0- 1- 0 1	7 1 7					
		0- 1- 0 1	8 1 8					
		0- 1- 0 1	9 1 9					
		0- 1- 0 1	10 1 10					
		0- 1- 0 1	11 1 11					
		0- 1- 0 1	12 1 12					
		0- 1- 0 1	13 1 13					
		0- 1- 0 1	14 1 14					
		0- 1- 0 1	15 1 15					
		0- 1- 0 1	16 1 16					
		0- 1- 0	1					
		0- 1- 0	1					
		0- 1- 0	1					
		0- 1- 0	1					
		0- 1- 0	1					

		0-	1				
		1-	0				
		0-	1				
		1-	0				
		0-	1				
		1-	0				
		0-	1				
		1-	0				
		0-	1				
		1-	0				
		0-	1				
		1-	0				
		0-	1				
		1-	0				

7.17 P30 set communication reading servo related variables


Chapter IX MODBUS Communication

This series of drives has two RS485 interfaces, which can communicate with the computer through USB-to-485 communication line for parameter setting, or control the drive to run the internal multi-segment position or multi-speed mode through the RS485 master station controller.

9.1 Wiring and Setup

9.1.1 Topology structure

CN3 and CN4 of the drive are RS485 interfaces. For specific pin definitions, please refer to chapter 4.3.1. When multiple nodes are used for communication control, a bus topology should be used, and the last one needs to be connected to a 120-ohm terminal resistor.




No.	Parameter name	Setting range	Factory setting

--	--	--	--

Note: To write parameters frequently, you need to set P0C-13 to 0 to prevent damage to the drive!

9.1.3 Communication address description

The communication address of the parameter can be calculated from the parameter number in the following method:



9.2 MODBUS communication protocol

9.2.1 Read register command (0x06)

Command sent by master station (PLC, etc.):

Byte order	Command example	Functional symbols	Functions

Byte order	Command example	Functional symbols	Functions

Byte order	Command example	Functional symbols	Functions

Byte order	Command example	Functional symbols	Functions

--	--	--	--

Byte order	Command example	Functional symbols	Functions

